

1 Before driving**1-1. Hybrid system**

Hybrid system..... 24

1-2. Key information

Keys 35

**1-3. Opening, closing and locking
the doors and trunk**Smart access system
with push-button start..... 39

Wireless remote control..... 51

Doors..... 54

Trunk..... 59

**1-4. Adjustable components
(seats, mirrors, steering wheel)**

Front seats..... 64

Driving position memory
system 66

Head restraints..... 70

Seat belts 74

Steering wheel..... 81

Inside rear view mirror 82

Outside rear view mirrors..... 83

**1-5. Opening and closing
the windows and moon roof**

Power windows..... 85

Moon roof 88

1-6. Refueling

Opening the fuel tank cap..... 91

1-7. Theft deterrent system

Immobilizer system 96

Alarm..... 98

Theft prevention labels
(U.S.A.)..... 100**1-8. Safety information**

Correct driving posture 101

SRS airbags 103

Front passenger occupant
classification system 115

Child restraint systems 121

Installing child restraints 125

2 When driving

2-1. Driving procedures

Driving the vehicle	138
Power (ignition) switch	148
Transmission	152
Turn signal lever	156
Parking brake	157
Horn	158

2-2. Instrument cluster

Gauges and meters	159
Indicators and warning lights	163
Multi-information display	166

2-3. Operating the lights and windshield wipers

Headlight switch	169
Fog light switch	172
Windshield wipers and washer	173
Headlight cleaner switch	178

2-4. Using other driving systems

Cruise control	179
Dynamic radar cruise control	183
Intuitive parking assist	195
Rear view monitor system	210
AVS (Adaptive Variable Suspension System)	213
Driving assist systems	214
PCS (Pre-Collision System)	221

2-5. Driving information

Cargo and luggage	227
Vehicle load limits	231
Winter driving tips	232
Trailer towing	236
Dinghy towing	237

3 Interior features

3-1. Using the touch screen

Touch screen	240
Setting the touch screen	243

3-2. Using the air conditioning system and defogger

Automatic air conditioning system	248
Rear window and outside rear view mirror defoggers	256
Windshield wiper de-icer	257

3-3. Using the audio system

Audio system type	258
Using the radio	261
Using the cassette player	270
Using the CD player	274
Playing MP3 and WMA discs	279
Using the DVD player	283
Playing DVD video/audio	286
Playing video CD (with DVD player)	298
CD/DVD player and DVD video disc information	302
Optimal use of the audio/video system	314
Using the AUX adapter	319
Using the steering switches	320

3-4. Using the hands-free system (for cellular phone)

Hands-free system (for cellular phone)	323
Using the Bluetooth [®] phone	328
Setting the hands-free system	343

3-5. Using the interior lights

Interior lights list	369
----------------------------	-----

3-6. Using the storage features

List of storage features	372
--------------------------------	-----

3-7. Other interior features

Sun visors	379
Vanity mirrors	380
Clock	381
Outside temperature display	382
Ashtrays	383
Cigarette lighter	384
Power outlet	385
Seat heaters/ventilators	386
Armrest	388
Rear sunshade	389
Floor mats	391
Trunk features	392
Garage door opener	394
Compass	400
Lexus Link System	404

4 Maintenance and care

4-1. Maintenance and care

- Cleaning and protecting the vehicle exterior 420
- Cleaning and protecting the vehicle interior 423

4-2. Maintenance

- Maintenance requirements 426
- General maintenance 428
- Emission inspection and maintenance (I/M) programs 431

4-3. Do-it-yourself maintenance

- Do-it-yourself service precautions 432
- Hood 435
- Positioning a floor jack 436
- Engine compartment 438
- Tires 452
- Tire inflation pressure 462
- Wheels 467
- Air conditioning filter 469
- Electronic key battery 472
- Checking and replacing fuses 474
- Headlight aim 489
- Light bulbs 492

5 When trouble arises

5-1. Essential information

- Emergency flashers 500
- If your vehicle needs to be towed 501
- If you think something is wrong 507
- Event data recorder 508

5-2. Steps to take in an emergency

- If a warning light turns on or a warning buzzer sounds 510
- If a warning message is displayed 519
- If you have a flat tire (Vehicles with standard tires) 536
- If you have a flat tire (Vehicles with run-flat tires) 546
- If the hybrid system will not start 547
- If the shift lever cannot be shifted from "P" 548
- If you lose your keys 549
- If the electronic key does not operate properly 550
- If the 12 volt battery is discharged 553
- If your vehicle overheats 557
- If the vehicle becomes stuck 560

TABLE OF CONTENTS

Index

6 Vehicle specifications

6-1. Specifications

Maintenance data (fuel, oil level, etc.).....	564
Fuel information.....	574
Tire information.....	577

6-2. Customization

Customizable features.....	590
----------------------------	-----

6-3. Initialization

Items to initialize	596
---------------------------	-----

7 For owners

Reporting safety defects for U.S. owners.....	598
Seat belt instructions for Canadian owners (in French)	599

Index

Abbreviation list.....	602
------------------------	-----

Alphabetical index	604
--------------------------	-----

What to do if... ..	614
---------------------	-----

